

MAXIMUS-3



JK WRANGLER

DUALLY AUXILIARY LIGHT BRACKETS

(Fits JK Wrangler with OEM Factory 10A/Hard Rock Steel Bumper)

PART #: HR1020AL

INSTALLATION STEPS

Estimated Install Time: 15 Minutes

PLEASE MAKE SURE YOU READ AND UNDERSTAND THE ENTIRE INSTALLATION GUIDE BEFORE YOU START. WE EXPECT YOU TO HAVE BASIC MECHANICAL ABILITIES TO PERFORM THIS INSTALLATION.

WE RECOMMEND THAT YOU SEPARATE AND IDENTIFY ALL THE PARTS AND HARDWARE KITS YOU RECEIVED WITH YOUR SHIPMENT BEFORE YOU PROCEED.



IMPORTANT

Follow these instructions precisely. Maximus-3 is not liable for any damage caused by improperly installed products. It is the purchaser's responsibility to ensure both the installation and maintenance are performed properly as set forth in this guide. We recommend using anti-seize paste on all non-thread lock bolts.

Component List:

JK Hard Rock Auxiliary Light Brackets

Qty

2

Hardware Kit

M6 Button Head Bolts

4

M6 Flat Washers

4

M6 Serrated Flang Nuts

4

Tools Required:

- ✓ Your basic hand tools
- ✓ T 35 Torx bit and ratchet

**INSTALLATION STEPS**

- 1- Using T35 torx bit, remove the four (4) factory bolts/screws from the bumper.
- 2- Align your Maximus-3 Auxiliary Light Brackets to the holes in the bumper and bolt down using the factory bolts or the supplied hardware. Refer to picture below.
 - If you have a winch installed, use the provided M6 serrated flange nuts under the bumper to fasten the bolts.
- 3- Bolt your Lights to the bracket as shown and route the wiring passing from under the grill and under the hood as desired, then connect following wiring instructions supplied by your lights manufacturer.



Your installation is complete. If you have questions regarding this installation, please contact us at sales@maximus-3.com or call 248-821-6654.